

Model 5100e

100 mm graphics recorder

User guide



EUROTHERM



EUROTHERM

Declaration of Conformity

Manufacturer's name:	Eurotherm Limited
Manufacturer's address	Faraday Close, Worthing, West Sussex, BN13 3PL, United Kingdom.
Product type:	Industrial graphics recorder
Models:	5100e Status level A1 and above
Safety specification:	EN61010-1: 1993 / A2:1995
EMC emissions specification:	EN61326
EMC immunity specification:	EN61326

Eurotherm Limited hereby declares that the above products conform to the safety and EMC specifications listed. Eurotherm Limited further declares that the above products comply with the EMC Directive 89 / 336 / EEC amended by 93 / 68 / EEC, and also with the Low Voltage Directive 73 / 23 / EEC

Signed: _____

Dated: _____

Signed for and on behalf of Eurotherm Limited
Peter de la Nougerède
(Technical Director)



IA249986U580 Issue 1 Jan 2001

© 2001 Eurotherm Limited

All rights are strictly reserved. No part of this document may be reproduced, modified, or transmitted in any form by any means, nor may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without the prior written permission of Eurotherm limited.

Eurotherm Limited pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. Eurotherm Limited will accept no responsibility for any losses arising from errors in this document.

GRAPHICS RECORDER

USER MANUAL

LIST OF CONTENTS

Section	Page
SAFETY NOTES	5
SYMBOLS USED ON THE RECORDER LABELLING	5
1 INTRODUCTION	6
1.1 UNPACKING THE RECORDER	6
2 INSTALLATION	6
2.1 MECHANICAL INSTALLATION	6
2.2 ELECTRICAL INSTALLATION	8
2.2.1 Signal wiring	8
CONNECTOR WIRING DETAILS	8
2.2.2 Supply voltage wiring	9
AC SUPPLY	9
2.3 DISK INSERTION AND REMOVAL	9
3 PROCESS VARIABLE DISPLAY	10
TRUNCATION OF NUMERIC VALUES	10
CURRENT TRACE ALARM ICONS	10
3.1 STATUS BAR	11
3.1.1 Current access level	11
3.1.2 Page name	11
3.1.3 Error/alarm indicators	11
SYSTEM ERROR	12
CHANNEL ALARM	13
CHANGE BATTERY	13
3.1.4 Disk icon	13
3.1.5 FTP Icon	13
3.2 NAVIGATION KEYS	14
3.2.1 Key functions	14
3.3 FIRST SWITCH-ON	15
3.3.1 Access to Configuration	15
TEXT STRING ENTRY	16
3.4 DISPLAY MODES	18
3.4.1 Vertical Trend display	18
TREND REVIEW	18
3.4.2 Horizontal Trend display	20
3.4.3 Vertical bargraph	22
3.4.4 Horizontal bargraph	23
3.4.5 Numeric	24

(Continued)

LIST OF CONTENTS (Cont.)

Section	Page
4 SETTING UP THE RECORDER	25
4.1 ARCHIVE	26
4.1.1 Archive to disk	26
4.1.2 Remote archiving (FTP transfer)	27
4.2 SAVE / RESTORE	28
4.2.1 Save	29
4.2.2 Restore	29
4.2.3 New	29
4.2.4 Text	29
4.3 CONFIGURATION	30
4.3.1 Options	30
4.3.2 Channel/Alarm configuration	32
CHANNEL NUMBER	33
INPUT TYPE	33
LIN TYPE	33
INPUT LOW	33
INPUT HIGH	33
SHUNT	33
RANGE LOW	34
RANGE HIGH	34
RANGE UNITS	34
SCALED	34
OFFSET	34
FILTER	34
INPUT BREAK RESPONSE	34
COLD JUNCTION COMPENSATION (CJC)	34
DESCRIPTOR	35
SPANNED	35
ZONE	35
MAXIMUM DECIMAL DIGITS	35
COLOUR	35
ALARM NUMBER	35
ENABLE	36
TYPE	36
THRESHOLD/HYSTERESIS	36
EXAMPLE	36
DWELL	36
JOB NUMBER	36
CATEGORY	36
WHILE	36
ALARM MESSAGES	36
4.3.3 Group configuration	37
TREND UNITS	37
DESCRIPTOR	37
TREND SPEED/TREND INTERVAL	37
RECORDING SPEED/RECORDING INTERVAL	37
ALARM MESSAGE	37
ACK MESSAGE	37
GROUP CONTENTS	37
4.3.4 Event configuration	38
EVENT NUMBER	38
SOURCE	38
DESCRIPTOR	38
JOB NUMBER	38
CATEGORY	38
WHILE	38

(Continued)

LIST OF CONTENTS (Cont.)

Section	Page
4.3.5 Instrument configuration	39
INSTRUMENT NAME	39
NORMAL/SAVER DISPLAY	39
SAVE AFTER	39
4.3.6 Archive configuration	40
COMPRESSION	41
FLASH SIZE	41
TREND HISTORY DURATION	41
SHOW	41
ARCHIVE TO MEDIA	41
MEDIA FULL OPERATION	41
MEDIA SIZE	41
DISK ARCHIVE CAPACITY	41
ARCHIVE TO REMOTE	42
REMOTE PATH	42
PRIMARY REMOTE HOST	42
PRIMARY LOGIN NAME/PASSWORD	42
SECONDARY REMOTE HOST/LOGIN/PASSWORD	42
4.4 SECURITY	43
4.4.1 Access levels	43
SETTING PERMISSIONS	43
ACCESS WHEN:	44
NEW PASSWORD/RETYPE PASSWORD	44
CONNECT FROM REMOTE	44
REMOTE USER NAME/PASSWORD	44
LOGIN DISABLED	44
EDIT OWN PASSWORD	45
CHANGE ALARM SETPOINTS	45
SET CLOCK	45
ARCHIVING CONTROL	45
SAVE/RESTORE	45
PASTE/DELETE FILES	45
FULL CONFIGURATION	45
FULL SECURITY	45
4.4.2 Add user	46
NEW USER/NEW PASSWORD/RETYPE PASSWORD	46
BASED ON	46
4.4.3 Remove user	46
4.5 NETWORK CONFIGURATION	47
4.5.1 Address	47
INSTRUMENT NUMBER/MAC ADDRESS	47
IP ADDRESS LOOKUP	47
BOOTP TIMEOUT	47
IP ADDRESS	47
SUBNET MASK	47
DEFAULT GATEWAY	47
4.5.2 Name	48
LOCAL HOST	48
DOMAIN	48
DOMAIN NAME SERVICE (DNS)	48
PRIMARY/SECONDARY DNS SERVER	48
4.6 STSTEM	49
4.6.1 Setup	50
HOME TIMEOUT	50
4.6.2 Clock	50
4.6.3 Locale	50
4.6.4 Keycode	51
4.6.5 About	51

(Continued)

LIST OF CONTENTS (Cont.)

Section	Page
5 FILE	51
5.1 FILER OPTION MENU KEYS	51
5.2 THE HIDE KEY	51
6 BRIDGE 5000 REMOTE VIEWER	53
6.1 INTRODUCTION	53
6.1.1 Minimum PC requirements	53
6.2 CONNECTION DETAILS	53
6.2.1 Direct PC connection	53
6.2.2 PC To remote recorder	54
6.2.3 Networked systems	54
6.3 SOFTWARE INSTALLATION	54
6.4 RECORDER CONFIGURATION	55
6.4.1 Network	55
6.4.2 Options	55
6.4.3 Access	56
6.5 RUNNING THE PROGRAM	57
6.6 OPERATION	58
6.6.1 Display Modes	58
6.6.2 Alarm acknowledgement	58
6.6.3 Status line	58
6.6.4 Error messages	58
NETWORK CONNECTION HAS TIMED OUT	58
UNABLE TO CONNECT TO HOST	58
UNABLE TO RESOLVE HOSTNAME	58
FAILED TO AUTHENTICATE THE USER NAME AND /OR PASSWORD SUPPLIED	58
MAXIMUM REMOTE VIEWERS ALREADY CONNECTED TO ...	58
7 REFERENCE	59
7.1 DIAGNOSTICS DISPLAY	59
7.1.1 Display details	59
MAC ETHERNET ADDRESS	59
COLOUR TEST BARS	59
SOFTWARE VERSION NUMBER	59
SELF-TEST STATUS BARS	59
CIRCUIT BOARDS FITTED	60
TOUCH CAL	60
DETAIL	60
7.2 SCREEN CALIBRATION (OFFSET CORRECTION)	61
7.3 PREVENTIVE MAINTENANCE	61
7.3.1 Touch Screen Cleaning	61
7.3.2 Maintenance schedule	62
7.3.3 Battery replacement procedure	62
7.4 MENU STRUCTURE	63
ANNEX A: SPECIFICATION	67
RECORDER	68
UNIVERSAL INPUTS	69
ETHERNET/RELAY OUTPUT BOARD OPTION	71
INDEX	72

SAFETY NOTES

WARNING

Any interruption of the protective conductor inside or outside the apparatus, or disconnection of the protective earth terminal is likely to make the apparatus dangerous under some fault conditions. Intentional interruption is prohibited.

Note: in order to comply with the requirements of safety standard BS EN61010, the recorder shall have one of the following as a disconnecting device, fitted within easy reach of the operator, and labelled as the disconnecting device.







- a. A switch or circuit breaker which complies with the requirements of IEC947-1 and IEC947-3
- b. A separable coupler which can be disconnected without the use of a tool
- c. A separable plug, without a locking device, to mate with a socket outlet in the building.

1. Before any other connection is made, the protective earth terminal shall be connected to a protective conductor. The mains (supply voltage) wiring must be terminated within the connector in such a way that, should it slip in the cable clamp, the Earth wire would be the last wire to become disconnected.
2. In the case of portable equipment, the protective earth terminal must remain connected (even if the recorder is isolated from the mains supply), if any of the I/O circuits are connected to hazardous voltages*.
3. The mains supply fuse within the power supply is not replaceable. If it is suspected that the fuse is faulty, the manufacturer's local service centre should be contacted for advice.
4. Whenever it is likely that protection has been impaired, the unit shall be made inoperative, and secured against accidental operation. The manufacturer's nearest service centre should be contacted for advice.
5. Any adjustment, maintenance and repair of the opened apparatus under voltage, should be avoided as far as possible and, if inevitable, shall be carried out only by a skilled person who is aware of the hazard involved.
6. Where conductive pollution (e.g. condensation, carbon dust) is likely, adequate air conditioning/filtering/sealing etc. must be installed in the recorder enclosure.
7. Signal and supply voltage wiring should be kept separate from one another. Where this is impractical, shielded cables should be used for the signal wiring.
8. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment might be impaired.

* A full definition of 'Hazardous' voltages appears under 'Hazardous live' in BS EN61010. Briefly, under normal operating conditions, hazardous voltages are defined as being > 30V RMS (42.2V peak) or > 60V dc.

SYMBOLS USED ON THE RECORDER LABELLING

One or more of the symbols below may appear as a part of the recorder labelling.

	Refer to the manual for instructions
	Protective earth
	This recorder for ac supply only
	This recorder for dc supply only
	This recorder for either ac or dc supply
	Risk of electric shock

USER GUIDE

1 INTRODUCTION

This document describes the installation, operation and configuration of a 100mm graphics recorder. The recorder has the facility for FTP transfer and Remote viewer connection if the Ethernet option is fitted.

1.1 UNPACKING THE RECORDER

The recorder is despatched in a special pack, designed to give adequate protection during transit. Should the outer box show signs of damage, it should be opened immediately, and the recorder examined. If there is evidence of damage, the instrument should not be operated and the local representative contacted for instructions. After the recorder has been removed from its packing, the packing should be examined to ensure that all accessories and documentation have been removed. The packing should then be stored against future transport requirements.

2 INSTALLATION

2.1 MECHANICAL INSTALLATION

Figures [2.1a](#) gives installation details.

Note: It is recommended that the rear face of the panel be centre-punched at suitable positions to locate the tips of the case clamps. Otherwise, particularly on smooth surfaces, the clamps can 'wander' as they are tightened, leading to inefficient clamping and possible damage to the recorder mounting slots.

The unit is inserted through the panel aperture from the front of the panel. With the weight of the recorder supported, a panel clamp is inserted into each of the mounting slots (one each on the left- and right-hand sides). The jacking screws are then tightened sufficiently to clamp the recorder into position. **EXCESS FORCE SHOULD NOT BE USED IN TIGHTENING THESE SCREWS.**

2 INSTALLATION (Cont.)





Figure 2.1a Mechanical installation details - small frame unit

2.2 ELECTRICAL INSTALLATION

2.2.1 Signal wiring

Figure 2.2.1a shows connector locations for the input channel and for the optional relay output/ethernet board

CONNECTOR WIRING DETAILS

- Maximum wire size (inputs) = 4.13mm² (11 AWG)
- Maximum wire size (relay) = 1.5 mm² (16 AWG)
- Minimum wire size = 0.081mm² (28 AWG)
- Design torque = 0.8Nm.

Figure 2.2.1b shows details of input board wiring and figure 2.2.1c shows relay output wiring.




Figure 2.2.1a Connector locations - small frame units




Figure 2.2.1b Input board wiring details




Figure 2.2.1c Relay wiring details

2.2.2 Supply voltage wiring

AC SUPPLY

The supply voltage to the recorder is terminated using an IEC socket which is connected to the mating plug at the rear of the recorder. The recorder is suitable for use with all ac voltages between 85 and 265 V RMS (47 to 63 Hz), and requires 60 VA max. power.

The minimum recommended wire size is 16/0.2 (0.5mm²).

2.3 DISK INSERTION AND REMOVAL

The disk slot is located below the recorder screen, and is protected by a flap as shown in figure 2.1, above.

In order to access the disk slot, the bottom of the central part of the flap is lifted (figure 2.3a) and then used as a handle to pull the main flap open.

If a disk is already fitted, it is removed by pressing on the eject button (figure 2.3b).

Note: Before disk removal, archiving should be suspended (section 4.1) (wait for the green LED on the disk drive to be extinguished), otherwise data might be lost.




Figure 2.3a Disk access




Figure 2.3b Disk eject

3 PROCESS VARIABLE DISPLAY

The operator interface consists of a touch-sensitive screen, showing either process variable values in one of a number of formats, or, showing configuration or operational details for use in setting up the recorder. This section (3) describes the process variable displays. Section 4 describes the Configuration displays.

Figure 3, below, depicts a typical trend display and gives details of the various areas of the display page.

TRUNCATION OF NUMERIC VALUES

If the amount of space on the display page is insufficient to display the full width of the process variable or scale value, then the displayed value is rounded down and the number of decimal places reduced.

CURRENT TRACE ALARM ICONS

In each of the different types of PV display, each channel's faceplate give the status of the channel's two alarms. This status is shown by a red arrow head, pointing upwards if the alarm is absolute high, or downwards if absolute low. As described in section 4.3.2 (Channel/alarm configuration) the alarms may be both high, or both low, or one may be high and the other low. If the arrow head is flashing it is active and unacknowledged; if it is on continuously, the alarm is active and acknowledged. See section 3.1.3, below, for a description of how to acknowledge alarms.




Figure 3 Trend display definitions

3.1 STATUS BAR

This appears across the top of the display, and contains the items described below.

3.1.1 Current access level

There are four access levels available (Logged out, Operator, Engineer and Service), and the current level is displayed in this key at the top left hand corner of the display. Touching this key calls the root menu as described in section 3.2.1 ([Key functions](#)) below. If 'user IDs' have been entered in the 'Add User' part of the Security setup, then the current user Id is displayed instead of the access level.

3.1.2 Page name

Initially this shows the current group's descriptor. The name changes according to context for example 'Operator' or 'Config-Archive'.

3.1.3 Error/alarm indicators

This area of the display can contain up to four icons: System error, Channel alarm, Battery change, Disk status. Pressing this area of the screen calls a pop-up display (figure 3.1.3) giving the option to view messages or to acknowledge channel alarms. Also incorporated in this display is a slider control allowing the user to optimise the display contrast for the local environment.




Figure 3.1.3 Alarm acknowledgement /System error display / Display contrast pop-up

3.1.3 ERROR/ALARM INDICATORS (Cont.)

SYSTEM ERROR



This indicator appears, flashing, if any of the following errors are active. The view messages page shows any active errors:

Archive failed -(message)	Message explains archive failure - due to disk being missing, write protected, faulty, full etc.
Clock failure	Internal clock was corrupt at power up, or the time has never been set. Can be caused by battery failure, in which case the battery icon will also be visible. The error is cleared by setting the time and date.
Battery-backed RAM cleared	This message appears if the battery has failed, and the unit has been switched off.
Channel failure	Indicates a hardware failure in the channel circuit
Channel error	Indicates a hardware failure in the channel circuit or in the internal CJ temperature measurement
Failed to authenticate the user name and/or password supplied	Appears if an incorrect user name or password has been entered whilst trying to establish remote viewer connection.
Floppy disk worn	Appears if a number of attempts had to be made before write to the disk was successful. No data is lost, but the disk should be replaced as soon as is practicable.
Floppy disk corrupt	This appears if all attempts to write to the disk fail. In such a case, some data may be lost. If the damaged area of the disk is in the system part of the disk, it might appear to the recorder that it is unformatted, and the disk icon will disappear. The disk should be replaced immediately.
Internal flash: \user\ required repair	Error found (in the internal file system) at power-up, and corrected.
Internal flash: \system\ required repair	Error found (in the internal file system) at power-up, and corrected.
Internal flash: \history\ required repair	Error found (in the internal file system) at power-up, and corrected.
Maximum Remote Viewers already connected to ...	Appears if an attempt is made to connect more remote viewers to the recorder than are configured in the Options menu.
Network connection has timed out	Appears if no connection can be established between the remote viewer and the recorder. This might be caused by, for example, cable failure, network hardware failure, etc.
Unable to connect to host ...	As for 'Network connection has timed out' message above, but with the addition of 'incorrect host address' as a possible cause.
Unable to resolve hostname	Message appears if an incorrect host address is entered or if there is a network failure whilst trying to establish remote viewer connection.

3.1.3 ERROR/ALARM INDICATORS (Cont.)

CHANNEL ALARM

This red 'bell' indicator appears if any channel is in alarm. The symbol is illuminated continuously if all alarms are acknowledged or flashes if any active alarm is unacknowledged. To acknowledge all unacknowledged alarms, the flashing indicator is touched, and the 'Ack all Alarms' key in the resulting 'pop-up' page is touched.

CHANGE BATTERY

This flashing indicator first appears when the battery voltage indicates that the battery is approaching the end of its useful life. The indicator continues to flash until the battery is replaced ([Section 7.3.2](#)).

3.1.4 Disk icon

This shows the free space available on the disk. The disk icon appears soon after a disk is inserted.

Only archiving activity is indicated; during archiving, the central area of the disk icon flashes green, regularly. No other disk activity is indicated.





Figure 3.1.4 Archive activity indication

3.1.5 FTP Icon

For those recorders fitted with Ethernet option, the File Transfer Protocol (FTP) icon appears to the right of the disc icon position, whenever transfer activity is taking place.

3.2 NAVIGATION KEYS

These keys allow the user to perform various context-related tasks such as to access the [recorder configuration](#), to [archive data](#) etc. In addition to this, left and right arrow keys or open/close folder keys appear where relevant.



3.2.1 Key functions

Close folder	Used, where appropriate, to recall the previous (higher level) display page.
Open folder	Used, where appropriate, to call a further (lower level) display page.
Left cursor	Used to navigate backwards through a text string, when editing.
Right cursor	Used to navigate forwards through a text string, when editing.
Root	Calls the 'Root Menu' as shown.

Root Menu	
Home	Operator
File	Cycle
Login	Options

ROOT MENU KEYS

Home	Causes a return to the 'Home' page from any page in the recorder. As delivered, the 'Home' page is the vertical trend display as depicted in figure 3, but this can be edited (in Operator/System - Setup) to be any of the available display modes - Horizontal trend, Vertical bargraph, Horizontal bargraph, Numeric etc.
Operator	Causes the top level Operator page to appear. The appearance of this display is dictated by the security level that the recorder is set to, and by the access level of the user. As despatched from the factory, the recorder is in 'logged out' mode and the Operator page contains only the buttons labelled 'Archive', 'Security' and System. Further details appear in ' Access to configuration ' below.
File	Allows the file system in that area of Flash memory that is accessible to the user, and the file system on any floppy disk fitted to be viewed. See section 5 for details.
Cycle	Causes the next display mode to be selected for process variable display. Initially, the sequence is Trace (on white background), vertical bargraph, horizontal bargraph, numeric. Though the order in which these displays appear cannot be changed, all modes can be enabled/disabled in the Operator/System-Setup configuration page. Tracing on a dark background is an alternative mode to tracing on a white background, not an additional mode.
Login	Calls the login page described in section 3.3.1, below
Options	Used for a number of functions depending on the context. For example, entering or exiting trend review mode, or calling the filer option pop-up.

To quit the Root menu, touch the root key again.

3.3 FIRST SWITCH-ON

There is no on/off switch associated with the recorder.

When power is applied the recorder initialises, and once this process is complete, the home page is displayed. It is unlikely that this will contain any useful information because the input channels will not, as yet, have been configured to suit the type of input signals being applied to them, as described in [section 4](#).

The recorder has four security levels as follows

Logged out	Initially, no access to recorder configuration is possible. Only Archive, Login/security and the System 'About' functions can be accessed - via the root menu. Limited or full access can be permitted from 'Engineer' level.
Operator	No access to recorder configuration is possible until access permission has been set up. Limited or full access can be permitted from 'Engineer' level, either with or without a separate password.
Engineer	Accessed initially, by entering '10' as the password. Full access to all recorder functions is available. The Engineer password can be edited and an Operator level password can be entered. Access permission to some or all of the recorder functions can be granted, or not, to the operator and/or logged out security levels.
Service	Full access to all recorder functions and to areas of recorder memory for diagnostic purposes. For use only by Service Engineers.

3.3.1 Access to Configuration

- 1 Once the recorder has initialised, touch the Root key, followed by 'Login'. Touching the 'Logged out' field in the resulting display, calls the access level picklist as shown in figure 3.3.1a.
- 2 Press 'Engineer' to call the Password request page.
- 3 Touching the blank Password area calls the keyboard display (see figure 3.3.1b).
- 4 Touch <Numeric><1><0><OK> to enter the password '10'. The screen reverts to the 'Home' page.
- 5 Operation of the [Root](#) key followed by a touch on the Operator key calls the top level page allowing access to the [Archive](#), [Save/Restore](#), [Config](#), [Security](#), [Network](#)*, and [System](#) areas described in section 4 below.




Figure 3.3.1a Access to configuration

* Network configuration appears only if the Ethernet option is fitted.

3.3.1 ACCESS TO CONFIGURATION (Cont.)

TEXT STRING ENTRY

The keyboard which appears when the password area is touched is the same as that which appears when any non-numeric text string entry is required (e.g. channel descriptor). Figures 3.3.1b and 3.3.1c below are an attempt, within the limitations of the illustrating process, to depict the available keyboards and thus the available character set. Actual entry of the text string is by touching the relevant key. For items which require only a numeric entry (e.g. channel range) the numeric keyboard appears.

When editing existing text strings, the existing text string appears highlighted, and will be replaced in its entirety by the first character entered. To avoid this, the left arrow key can be touched to 'unhighlight' it.

Immediately below the keyboard are six keys with the functions listed below. When active, the background colour changes to yellow for as long as the key is active.

- Shift* Once the shift key has been pressed, the next-entered letter appears as a capital; subsequent letters are in lower case.
- Caps* When pressed, all subsequent letters appear as capital letters until the Caps key is operated again
- BSpC This backspace key deletes character to the left of the cursor.
- Ovr If selected, the next-entered character replaces (overwrites) the existing character to the right of the cursor position. If not selected, the next-entered character is inserted into the existing text string at the cursor position.
- Ok Used to save the new text string and to return to the page from which the keyboard was called.
- Cancel Causes a return to the page from which the keyboard was called without saving the new string.

*Note: The character on each display key is always a capital letter, whether or not the actual character being entered is in capitals or lower case.




Figure 3.3.1b Alphabet 1 keyboard

3.3.1 ACCESS TO CONFIGURATION (Cont.)

TEXT STRING ENTRY (Cont.)






Figure 3.3.1c Alternative keyboards

3.4 DISPLAY MODES

The display modes described below allow process values (also known as points) to be displayed as vertical or horizontal 'chart' traces (Trend modes), as bargraphs (vertical or horizontal) or as numeric values. The various display modes are cycled-through using the [Root menu\Cycle](#) key. The [Home](#) key returns the user to the Home page from anywhere in the Operator or Configuration pages in the recorder. The display mode associated with the home page is Vertical Trend when dispatched, but any of the other display modes can be selected as the home page in [System - Setup](#).

3.4.1 Vertical Trend display

This (default) display (figure 3.4.1) shows each point in the display group as though it were being traced on a white chart. (It is possible to display on a black 'chart' instead, by selecting Dark Trend Background in [System - Setup](#).) In either case, some thought should be given to trace colours selected in channel configuration. When selected, dark background applies to both vertical and horizontal trend display modes.

One of the channels is defined as being the 'current' or 'scale' channel, and this is identified on the chart by its diamond shaped pen icon. The current channel's descriptor, digital value and scale are displayed on a channel faceplate which lies between the chart and the status bar. To scroll through the channels, this faceplate area is repeatedly touched, with each touch increasing the channel number by one. To select a particular channel to be the current channel, the relevant pen icon can be touched (briefly, otherwise Trend Review mode will be entered). In either case, the background colour of the channel descriptor takes the colour of the current channel. If a channel is included in the display group but its status is 'not good' for some reason, then its pen icon is hollow.

TREND REVIEW

Trend review, or trace history, allows the user to view the history of the display group. The maximum amount that can be reviewed depends on a number of factors, including how many points are configured, how rapidly the traces are changing and so on. At a recording rate of 20mm/hour (see [group configuration - section 4.3.3](#)), with all channels configured, a minimum of 30 day's worth of traces is available for viewing, provided that the group contents are not re-configured during this period (in which case, the history starts at the end of the re-configuration). The amount of trace visible on the screen depends on the recording rate - the higher the rate, the less trace is visible at any one time.

To enter trend review, the option key can be used (as shown in figure 3.4.1), or the trace area of the screen can be continuously touched until the screen blanks prior to re-drawing. A 'Preparing History, please wait' message appears whilst the re-drawing calculation is taking place. Although tracing stops during trend review, no data is lost - Process Variable values are still saved in the recorder memory and alarms are still scanned-for and any associated action taken.

The trend review display is similar to the real-time vertical trend display, with the addition of a slider control and of up and down keys for selecting that part of trend history which is to be displayed. The controls are used as follows:

- 1 Touching the up/down key causes the trace history to move an incremental amount.
- 2 Holding the up/down key continuously, causes continuous movement.
- 3 Touching the bar above or below the slider causes a page-height shift.
- 4 Touching and dragging the slider, whilst observing the time/date display, allows the user to select the section of history exactly.

On first entry to the trend review mode, the channel value and the time and date shown in the faceplate are those at the top edge of the chart. Touching the screen causes a cursor to appear at point of screen contact. This cursor can be touched and dragged up and down the screen to provide a reference point on the current trace. The displayed value date and time refer to the cursor intersection with the current channel. To return to real-time trending, the Options key in the root menu is operated, followed by 'Exit Review'.

To call the Horizontal trend display, press the root key, followed by 'Cycle'.

3.4 DISPLAY MODES (Cont.)





Figure 3.4.1 Vertical Trend display mode and trend review mode

3.4 DISPLAY MODES (Cont.)

3.4.2 Horizontal Trend display

Entered from the Vertical Trend display by use of the Root Menu 'Cycle' key, this display (figure 3.4.2a) is similar to the Vertical Trend display described above, except that the traces are produced horizontally rather than vertically.

Figure 3.4.2a Horizontal trend display mode



One of the channels is defined as being the 'current' or 'scale' channel, and this is identified on the chart by its pen icon being diamond shaped rather than triangular as used for non-current channels. If a channel is included in the display group but its status is 'not good' for some reason, then its pen icon is hollow.

There are two faceplates associated with this display, one above the 'chart', showing the current channel descriptor and its digital value; the other - to the right of the chart - showing a bargraph representation of the current channel's value together with a scale showing the low and high range values for the channel. Touching either of these faceplates causes the current channel number to increment. To select a particular channel to be the current channel, the relevant pen icon can be touched (briefly, otherwise Trend Review mode will be entered). In either case, the bargraph and the background colour of the channel descriptor takes the colour of the current channel.

There is no horizontal trace review function - touching the 'chart' for a few seconds (or using the Root menu Options key, then 'Enter Review') calls the vertical trend history page described in section 3.4.1, above.

Time and date are printed on the 'chart' immediately to the right of alternate vertical grid lines, and it is these grid lines to which the printed time relates.

3.4.2 HORIZONTAL TREND MODE (Cont.)

Below the 'chart', is a message bar, containing the latest message. If there is more than one message, an arrow head icon appears near the right hand end of this message bar, and if this appears, then touching the message bar calls a pop-up box (figure 3.4.2b) in which all relevant messages are displayed.




Figure 3.4.2b Horizontal trend mode message dialogue box

To call the Vertical Baraph display, press the root key, followed by 'Cycle'.

3.4 DISPLAY MODES (Cont.)

3.4.3 Vertical bargraph

Entered from Horizontal Trend mode by means of the Root Menu 'Cycle' key, this display mode shows the Process Variable (PV) values as vertical bars with faceplates containing digital values and alarm data. Review mode is not available from this display mode.

Operation of the Root menu Options key calls the Option menu display for this display page, allowing faceplates to be selected on or off. This selection is not 'saved' at power down - the recorder always powers-up with faceplates selected 'On'. This feature is available for vertical bargraph displays only.

To call the Horizontal Bargraph display, press the root key, followed by 'Cycle'.




Figure 3.4.3a Vertical bargraph display (with faceplates)




Figure 3.4.3b Vertical bargraph display (faceplates off)

3.4.4 Horizontal bargraph

Entered from Vertical bargraph mode by means of the root menu 'Cycle' key, this display mode shows the Process Variable (PV) values as horizontal bars with digital values and alarm data displayed, as shown in figure 3.4.4. Review mode is not available from this display mode.

To call Numeric display mode, press the root key, followed by 'Cycle'.




Figure 3.4.4 Horizontal bargraph display

3.4 DISPLAY MODES (Cont.)

3.4.5 Numeric

Entered from Horizontal bargraph mode by means of the root menu 'Cycle' key, this display mode shows the Process Variable (PV) values as digital values. The format (which is automatically selected) is based on the number of channels in the display group. Figures 3.4.5a and 3.4.5b, show typical examples of the one column (up to four channels) and two column versions (five or six channels) of this display mode, respectively. Within each version, the process variable display areas expand or contract to fill the screen. Review mode is not available from this display mode.

A further operation of the Cycle key in the Root menu returns to Vertical Trend Display mode described above.




Figure 3.4.5a Numeric display mode (1 to 4 channels)




Figure 3.4.5b Numeric display mode (5 or 6 channels)

4 SETTING UP THE RECORDER

As described in the '[Access to Configuration](#)' (section 3.3.1) above, the setting-up of the recorder is divided into the following areas:

Archive	Section 4.1 - Allows manual archiving of data to disk or (if the Ethernet option is fitted) to a remote host (FTP transfer).
Save/restore	Section 4.2 - Allows new configurations to be created and saved, and saved configurations to be 're-stored'.
Config	Section 4.3 - This is the major channel/alarm/option etc. area of configuration.
Security	Section 4.4 - Allows passwords to be entered and edited and allows the Engineer-level password holder to enable/disable areas of configuration to Operator-level password holders. New users can be added, with their own user names, passwords and access level permissions.
Network	Section 4.5 - This area sets up the IP / mac address/host names etc. used in FTP transfer and Bridge 5000 applications (if the Ethernet option is fitted).
System	Section 4.6 - Allows time and date functions to be set and edited (including daylight saving start and finish dates, time zones etc.) The system key also allows the display language to be chosen, Option key codes to be entered, and contains an 'About' screen describing the software/hardware status of the recorder.

Note: In all the following descriptions, if a change is made to a menu item, then the item text changes from black to red, until it is 'saved'.

4.1 ARCHIVE

4.1.1 Archive to disk

This allows the user to initiate data transfer to a floppy disk, by touching the relevant key for `Archive Last Hour`, `Last Day`, `Last week`, `Last Month`, `All` to define which files are to be transferred. Archiving starts as soon as the selection is made, and cannot be stopped until completed, unless the Cancel archive key is operated, in which case the archive will be stopped after a confirmatory message has been responded to. The Cancel key is active only if 'Archiving Control' is enabled in Security/Access ([section 4.4](#) of this manual). Figure 4.4.1 shows the archive to disk menu.




Figure 4.1.1 Disk archive strategy configuration

If the disk becomes full before archiving is complete, archiving will pause and a pop-up request appears, asking for the disk to be replaced. If this request is not responded-to within 10 minutes of its appearance, archiving is aborted.

Unattended archiving can be paused by the user (e.g. to change disks without losing data) by operating the 'Suspend Archiving' button. Transfer activity is indicated in the 'Archive transfer' window. Should the disk become full, the user will be prompted to replace it with a different one.

Below the selection buttons are a number of status windows relating to the disk.

If automatic archiving is active ([section 4.3.6](#)), then this and the manual archive will operate on a first come-first served basis. Some files will be saved twice in such a circumstance, the later archive's files overwriting any earlier archive's files which have the same name.

4.1.2 Remote archiving (FTP transfer)

Note: Remote archiving is available only if the Ethernet option is fitted.

This allows archiving of recorder files to a remote computer, connected (using the RJ45 telephone type connector at the rear of the recorder) either directly, or via a network .

In order to carry out a successful transfer, details of the remote host must be entered in the Archive section of the 'Config' menu ([section 4.3.6](#)).

Note: An FTP server must be running on the remote host.

Figure 4.1.2 shows the archive menu for remote archiving. The Archive last hour/day/week etc. keys allow the user to determine which files are to be archived. The 'Last Archive' window shows the time and date of the previous archive. The Archive Transfer window shows archive status as 'Active' or 'Inactive'.




Figure 4.1.2 Remote archive strategy configuration

Additionally, a user on a remote PC has full viewing capabilities, can extract recorder files at any time, and can access those items of recorder configuration that are associated with the user's login. For successful connection, 'Connect from Remote' must be enabled and the 'Remote user name' and 'Remote password' must be defined in one of the accounts (all in the Security access menu ([section 4.4.1](#))).

Notes:

- In order to view history files when accessing the instrument remotely, the recorder's address, the 'Remote user name' and the 'Remote password' must be supplied to an FTP client such as PC Review or Microsoft® Internet Explorer.
- When accessing files using Microsoft® Internet Explorer, the address (URL) field can be in one of two forms:
 - ftp://<instrument IP address>. This allows the user to log in as the anonymous user (if the instrument has any account with 'Remote user name' set to 'Anonymous' and a blank password).
 - ftp://<user name>:<password>@<instrument IP address> to log in as a specific user.
- For IE5 users only: Microsoft® Internet Explorer displays, by default, history files only. To exit the history folder, either uncheck the Tools/Internet Options/Advanced/Browsing/"Enable folder view for FTP sites" option, or check the Tools/Internet Options/Advanced/Browsing/"Use Web based FTP" option.

4.2 SAVE / RESTORE

As shown in figure 4.2a, touching the Save/Restore key calls the picklist: Save, Restore, New, Text.




Figure 4.2a Save/Restore menu

For 'Save', 'Restore' and 'Text' (all described below) if the filename which appears is suitable, then operation of the 'Save' or 'Restore' key will initiate the action. If a filename has to be entered, this is carried out as follows:

Touching the filename window causes a pop-up menu to appear, giving a list of 'Volumes' in the Flash memory or on the floppy disk (if inserted). Figure 4.2b shows an imaginary Volume contents list, displayed by touching the name 'user', then operating the 'open folder' key. (See section 5, below for more details). Once the correct folder is open, either select an existing file, or enter a new filename, by touching the FileName window and entering the name using the pop-up keyboard(s) as described in section 3.3.1 above. Operation of the Save or Restore key initiates the action.

user\						Hide
Name	Type	Date	Bytes			
cal\	Folder	03/06/00 12:35:08				
config\	Folder	01/05/00 10:27:13				
Filter1a	Config	05/07/00 10:22:23	4445			
lib\	Folder	05/07/00 10:23:14				
sdb\	Folder	11/05/00 14:01:08				
FileName: Filter1b				Save	Cancel	

Figure 4.2b typical volume contents page

4.2.1 Save

Touching this item allows the current configuration to be saved in the recorder's memory. Files saved in this way are not in a 'readable' format and are used only for archive /security purposes or for transfer to another, similar, recorder.

4.2.2 Restore

Touching this item allows the user to select or type-in a previously saved configuration file name, which will then be used as the current configuration. Touching the 'Restore' key completes the operation. Tick boxes allow one or more of Configuration, Security or Network data to be chosen to be restored.

4.2.3 New

Touching this item causes the factory entered default configuration to be loaded for use, or for editing. Operation of the New/Default key completes the operation. Tick boxes allow one or more of Configuration, Security or Network data to be chosen to be restored.

4.2.4 Text

This is identical to the 'Save' function described above, but the configuration is saved in ASCII format, and can be transferred to a computer and read, printed etc. as required. It is not possible, using this means, to modify the configuration and then re-load it.

4.3 CONFIGURATION

Touching this key calls the top level configuration pick list: Options, Channels, Groups, Events, Instrument, Archive, as shown in the overview figure (figure 4.3b) below.

When making changes to the configuration the name of each changed parameter is displayed in red (instead of the normal black) until the 'Apply/Discard' key has been operated. For example, in channel configuration, if a thermocouple were to be changed from Type J to Type K, 'Lin Type' would appear in red, until the Apply key was operated.

Should an attempt be made to leave configuration with unsaved changes, a warning message appears, allowing the user to apply the changes, to discard the changes or to return to configuration (Cancel).



Figure 4.3a Data modification warning

4.3.1 Options




Figure 4.3.1 Options menu layout

Touching this key calls a display showing the current recorder hardware/software setup, for example the number of input channels fitted, whether or not an Ethernet/Relay output board is fitted. This page shows any differences between the hardware actually fitted and the hardware the recorder software is configured for (currently ...). Whenever there is a difference, the 'Autoconfigure' key can be pressed to alert the recorder to the fact that an option has been added (or removed).

If no changes have occurred since last switch-on, then the '(currently ...)' fields and the 'Autoconfigure' key do not appear.

4.3 CONFIGURATION (Cont.)




Figure 4.3b Configuration menu overview

4.3.2 Channel/Alarm configuration

Figure 4.3.2a below, shows a typical configuration menu. The actual fields that appear depend on what input type is selected, what linearisation type is selected, and so on.

The screenshot displays a configuration menu for a channel named '1) TurbineTempA'. The settings are as follows:

- Channel Number:** 1) TurbineTempA (dropdown menu)
- Input Type:** Thermocouple (dropdown menu)
- Lin Type:** Type K (dropdown menu)
- Range Low:** 0 °C
- Range High:** 1 °C
- Range Units:** °C (dropdown menu)
- Scaled:**
- Scale Low:** 0 V
- Scale High:** 1 V
- Units:** V
- Offset:** 0 V
- Filter:** None (dropdown menu)
- Break Response:** None (dropdown menu)
- Cold Junction Type:** Off (dropdown menu)
- Descriptor:** TurbineTempA
- Spanned:**
- Span Low:** 0 V
- Span High:** 1 V
- Zone Low:** 0 %
- Zone High:** 100 %
- Max Decimal Digits:** 4
- Colour:** 26
- Alarm Number:** 1 (dropdown menu)
- Enable:** Off (dropdown menu)
- Job Number:** 1 (dropdown menu)
- Category:** No Action (dropdown menu)

Buttons at the bottom: **Apply** and **Discard**.

Figure 4.3.2a Channel/alarm configuration menu (typical)

Notes

1. Numeric values (e.g. 'input low') can be up to 10 characters including decimal point
2. Refer to [section 3.3.1](#) for numeric and text entry techniques.

4.3.2 CHANNEL/ALARM CONFIGURATION (Cont.)

Example: A type J thermocouple is used to measure a temperature range of 100 to 200 degrees Celsius. This thermocouple output is transmitted to the recorder by a 4 to 20 mA transmitter, for display as an efficiency value between 0 and 100%. In such a case, the following values would be set up:

Input type = milliamp
Input range low = 4.0
Input range high = 20.0
Scale low = 0.0
Scale high = 100
Scale units = %
Linearisation range low = 100
Linearisation range high = 200
Linearisation type units = degrees C
Linearisation type = Type J thermocouple.
Input shunt value = 250 ohms

Note: The following description shows all possible fields. The recorder itself edits the list and shows only those fields appropriate to the setup so far. For example, the 'Shunt' field appears only for mA input type.

CHANNEL NUMBER

The current channel and its descriptor are displayed. Touching the window area allows another channel to be selected for configuration.

INPUT TYPE

Select thermocouple, millivolt, Volt, milliamp, RTD, Ohms, Test or Digital as input type.

LIN TYPE

The following linearisation tables are available as standard:

Linear, square root, $x^{3/2}$, $x^{5/2}$.

Thermocouple types B, C, D, E, G2, J, K, L, N, R, S, T, U, NiMo/NiCo, Platinel

Resistance thermometer (RTD) types Cu₁₀, Pt₁₀₀, Pt₁₀₀A, JPT₁₀₀, Pt₁₀₀₀, Ni₁₀₀, Ni₁₂₀.

For input ranges, accuracies etc. associated with the above, see the specification section of this manual.

INPUT LOW

Enter the lowest value to be applied to the input terminals (e.g.4.00).

INPUT HIGH

Enter the highest value to be applied across the input terminals (e.g. 20.00).

SHUNT

Allows a shunt resistor value to be entered for input type = mA. Commonly used values are 100 ohms and 250 ohms. Note that shunt resistors are connected to the input connector. The recorder cannot detect whether a shunt is fitted, or if one is, what value it has. Therefore it is the responsibility of the user to ensure that the ohmic value of any shunt fitted matches the shunt value entered in this field.

4.3.2 CHANNEL/ALARM CONFIGURATION (Cont.)

RANGE LOW

Enter the lowest value of the required linearisation range (e.g. 100)

RANGE HIGH

Enter the highest value of the required linearisation range (e.g. 200)

RANGE UNITS

Selectable from degrees Celsius, degrees Fahrenheit, Kelvin or Rankine.

SCALED

This box allows the user to select low and high values and units for a scale.

SCALE LOW

Enter the scale value to correspond with input range low (e.g. 0).

SCALE HIGH

Enter the scale value to correspond with input range high (e.g. 100).

SCALE UNITS

Enter up to eight characters of unit descriptor (e.g.%).

OFFSET

Allows a fixed value to be added to or subtracted from the process variable. Recorder accuracy figures no longer apply if an offset is included.

FILTER

For 'noisy' slowly changing signals, damping can be used to filter noise so that the underlying trend can be seen more clearly. None, 2, 4, 8, 16, 32, 64, 128 or 256 seconds can be selected.

It is not recommended that damping be used on quickly changing signals.




Figure 4.3.2b Channel filter

INPUT BREAK RESPONSE

For thermocouples and other low level inputs (i.e. input voltages less than 150mV), the recorder can be made to respond in one of the following ways, if a break in the input circuit is detected.

- None trace drifts with the input wiring acting as an aerial.
- Drive hi trace placed at full scale
- Drive lo trace placed at scale 'zero'

COLD JUNCTION COMPENSATION (CJC)

For input type = thermocouple, None, internal or external can be selected for cold junction compensation. Internal CJC is by means of an RTD connected across pins 11 and 12 of the input board connector. If the cold junction is maintained (by the user) at a known, fixed temperature, 'external' should be selected.

EXTERNAL CJ TEMPERATURE

If 'external' is selected as cold junction compensation, enter the temperature at which the cold junction is maintained.

4.3.2 CHANNEL/ALARM CONFIGURATION (Cont.)

DESCRIPTOR

Allows a text string of up to 20 characters (including spaces) to be entered for the channel descriptor. (E.G. 'Turbine 2 tempA').

SPANNED

This box, when selected, allows span low and high values to be entered. For example, in an input range of 0 to 600 deg C, it may be that the temperature range between 500 and 600 degrees is of most interest. In such a case, setting span low to 500 and span high to 600 will cause the recorder to display only that part of the input range, and this will fill the zone width (which is selected next), effectively magnifying the area of interest.

ZONE

This allows the portion of the chart which the channel occupies to be defined in terms of percent, where the left edge of the chart is 0% and the right hand edge is 100%. For example, setting a low value of 50 and a high value of 100 causes the channel trace to be confined to the right hand half of the chart.

MAXIMUM DECIMAL DIGITS

This defines the number of decimal places in the process value. Settable between zero and nine. Leading and trailing zeros are not displayed. Values too long for the available displaying width are truncated as described in [section 3](#).

COLOUR

Allows the trace colour to be selected from a colour chart. Each of the 56 available colours is displayed with a number, and it is this number which is entered. The background colour to the selection box changes to the selected colour.

ALARM NUMBER

Allows alarm one or alarm two to be selected for the channel. See the figure for definitions.

There are two alarm thresholds available per input channel. Each threshold can be defined as absolute high or absolute low. When the value lies above an absolute high threshold or below an absolute low threshold, an internal event becomes active and this event can be used to trigger a 'job' such as 'drive relay output'.




Figure 4.3.2c Absolute alarm definitions

4.3.2 CHANNEL/ALARM CONFIGURATION (Cont.)

ENABLE

Select Off, Unlatched, Latched or Trigger from the pick list. See [figure 4.3.2c](#) above for definitions

TYPE

Select absolute high or absolute low for this alarm.

THRESHOLD/HYSTERESIS

Allows values to be entered for the trigger setpoint and for hysteresis, both in engineering units.

EXAMPLE

Threshold = 100 units; Hysteresis = 5 units

A high alarm becomes active when its input rises above 100 and remains active until its value falls below 95 units. A low alarm becomes active when its input falls below 100 units, and remains active until its input rises above 105 units.

DWELL

Allows a dwell value to be entered as seconds. If an alarm trigger returns to a non-active state before the dwell period expires, then it is ignored.

JOB NUMBER

Select job one or two for this alarm.

CATEGORY

Select the required job to be carried out when the channel is in alarm (e.g. Drive relay)

Note: the relay is normally energised (common to normally open) and is de-energised (common to normally closed) in alarm or power off conditions.

WHILE

Allows the action of the alarm job to be chosen as whilst active, whilst inactive or whilst unacknowledged.

ALARM MESSAGES

Alarm on/off and alarm acknowledge message printing on the chart can be enabled/disabled as a part of 'Group configuration' described below. Alarms are acknowledged by touching the (flashing) alarm icon at the top of the screen, then touching the 'Ack all Alarms' key followed by the confirmation 'Yes' key ([section 3.1.3](#)).

4.3.3 Group configuration

This section allows the user to define trend speed/interval, recording speed/interval, a group descriptor and the group contents. Alarm messages can also be enabled or disabled in this area.

TREND UNITS

Allows mm/hr or inches per hour to be selected for the 'chart' speed. Automatically converts the trend speed field below.

DESCRIPTOR

Allows the group name to be edited. See [section 3.3.1](#) for text entry techniques.

The screenshot shows a configuration menu with the following items:

- Trend Units: with a dropdown arrow and a note "Select mm/hr or in/hr".
- Descriptor:
- Trend Speed: mm/hr
- Trend Interval: s
- Recording Speed: mm/hr
- Recording Interval: s
- Alarm Message:
- Ack Message:
- TurbineTempA:
- TurbineTempB:
- TurbineTempC:
- Etc.

At the bottom are "Apply" and "Discard" buttons. A legend box shows a checked box followed by "= Enabled".

Figure 4.3.3 Group configuration menu layout

TREND SPEED/TREND INTERVAL

Allows the 'chart' speed to be selected either as mm or in per hour, or as an interval. Entering a value in one field automatically converts the value in the other field. A trend interval of N seconds is equivalent to 1200/N mm/hr chart speed; a chart speed of P mm/hr is equivalent to a trend interval of 1200/P seconds.

RECORDING SPEED/RECORDING INTERVAL

As for trend speed/interval but defines the rate at which data is saved to Flash memory. This value also affects how much trace history appears per screen height in trend review mode ([section 3.4.1](#)).

ALARM MESSAGE

This box allows the printing of alarm on and off messages on the 'chart' to be enabled or disabled as required. Alarm messages appear on the trend display and in PC Review in the form HH:MM:SS Alarm ON n/m and HH:MM:SS Alarm OFF n/m, where 'n' is the relevant channel number and 'm' is the alarm number (1 or 2).

ACK MESSAGE

This tick box allows the printing of alarm acknowledgement messages on the 'chart' to be enabled or disabled as required. Acknowledge messages appear on the trend display and in PC Review in the form HH:MM:SS

ALARM ACKNOWLEDGE

Alarms are acknowledged by touching the (flashing) alarm icon at the top of the screen, then touching the 'Ack all Alarms' key.

GROUP CONTENTS

This appears as a number of tick-boxes, to include the ticked items in, or to exclude non-ticked items from, the group, as required.

4.3.4 Event configuration

Two internal alarm sources (events) are available for use in running a job list when triggered.

The screenshot shows the following configuration options:

- Event Number:** 1) Event 1 (Select 1 or 2)
- Source:** Off (Select: Off, Global alarm, Global Unack'd Alarm)
- Descriptor:** Event 1
- Job Number:** 1 (Select: 1 or 2)
- Category:** No Action (Select: No action, Drive Relay)

Buttons: Apply, Discard

Figure 4.3.4 Event configuration menu layout

EVENT NUMBER

Allows the required event to be selected for configuration.

SOURCE

Off	The event is disabled.
Global alarm	The event is active whilst any one or more alarms is active.
Unacknowledged alarm	The event is active as long as there is an unacknowledged alarm present.

DESCRIPTOR

Allows a text string to be entered as the event title. See [section 3.3.1](#) for text entry techniques.

JOB NUMBER

Select job one or two for this event.

CATEGORY


Select the required job to be carried out when the channel is in alarm (e.g. Drive relay).

Note: the relay is normally energised (common to normally open) and is de-energised (common to normally closed) in alarm or power off conditions.

WHILE

Allows the action of the alarm job to be chosen as whilst active, whilst inactive or whilst unacknowledged.

4.3.5 Instrument configuration



The screenshot shows a configuration menu with the following fields and values:

Instrument Name	Instrument
Normal Display	100 %
Saver Display	100 %
Save After	10 Minutes

Below the fields are two buttons: **Apply** and **Discard**.

Figure 4.3.5a Instrument Configuration menu

INSTRUMENT NAME

Allows the entry of an alphanumeric name for the recorder, up to 20 characters long. See [section 3.3.1](#) for text entry techniques.

NORMAL/SAVER DISPLAY

Allows normal and 'saver' display brightnesses to be defined. Defaults are both 100%

SAVE AFTER

The number of minutes (between 1 and 99 inclusive), which are to elapse after a screen operation, before the screen brightness changes from 'normal' to 'saver'.

4.3.6 Archive configuration

This allows an archive strategy to be set up for saving data to disk or (if the Ethernet option is fitted) to a remote PC. The disk strategy includes archive period, disk full operation, compression factor and an estimate of how much archive period is left in the recorder memory and on the disk. The recorder uses a dedicated area of its Flash memory as an archive data buffer; data is written to the disk or remote PC only when required, rather than continuously.

In order to carry out a successful remote archive, details of the remote host must be entered both in this Archive section of the 'Config' menu, and in Network configuration ([section 4.5](#)). Further, the current access level must have 'Connect from remote' enabled in the Security/Access menu ([section 4.4.1](#)).

Compression **Normal** ▼ → Select: Normal or High

Flash Size Mb

Trend History Duration Days

Show **Disk settings** ▼ → Select Disk or Remote settings

Archive to Media **None** ▼ → Select: None, Hourly, Daily, Weekly, Monthly or Automatic

On Media Full **Overwrite** ▼ → Select: Overwrite or Stop

Media Size Mb

Disk Archive Capacity Days

Figure 4.3.6a Archive configuration menu (Disk settings)

Compression **Normal** ▼ → Select: Normal or High

Flash Size Mb

Trend History Duration Days

Show **Remote settings** ▼ → Select: Hourly, Daily, Weekly, Monthly, Automatic

Archive to Remote **None** ▼ → Select: Hourly, Daily, Weekly, Monthly, Automatic

Remote path

Primary remote host

Primary login name

Primary password

Retype password

Secondary remote host

Secondary login name

Secondary password

Retype password

Figure 4.3.6b Archive configuration menu (Remote settings)

4.3.6 ARCHIVE CONFIGURATION (Cont.)

COMPRESSION

Select Normal or high compression. 'Normal' compresses the data but still provides an exact copy. 'High' compresses more, but channel values are saved only to 1 part in 10⁸ resolution.

FLASH SIZE

Allows the size of the Flash memory to be viewed by the user.

TREND HISTORY DURATION

Gives an estimated time to fill the trend history area of the Flash memory. The calculation is based on the archive rate, the compression ratio, the flash size and on the exact nature of the data. (Rapidly changing values use more space than static/slowly changing values.)

SHOW

This allows the fields which are to appear below 'Show' to be applicable to disk (Disk Settings), or to the setting up of a remote host path for archiving purposes (Remote settings). The following descriptions contain all the fields which may appear in either menu.

ARCHIVE TO MEDIA

For Disk Settings only:

None	Archive to disk is initiated by the operator (section 4.1)
Hourly	Archive to disk occurs on the hour every hour
Daily	Archive to disk occurs at 00:00* hrs each day
Weekly	Archive to disk occurs at 00:00* hrs every Monday
Monthly	Archive to disk occurs at 00:00* hrs on the 1st of each month
Automatic	The recorder selects the slowest out of Hourly, Daily, Weekly or Monthly, which is guaranteed not to lose data. This is calculated according to which of the trend history buffer or the disk is the smaller. The recorder assumes that the disk is 'empty' when making these calculations.

MEDIA FULL OPERATION

For Disk Settings only:

Overwrite	Oldest data replaced with latest data when disk is full
Stop	Archiving stops when the disk is full

MEDIA SIZE

For Disk Settings only:

Allows the size of the Disk to be entered, for user information only. This item is not saved as part of the configuration.

DISK ARCHIVE CAPACITY

For Disk Settings only:

Gives an estimated time to fill the disk, based on the archive rate, the compression ratio, the disk size and on the exact nature of the data. (Rapidly changing values use more space than static/slowly changing values.)

*Note: Archive times are not adjusted for Daylight Saving hour changes. Thus if the archive is set to 'daily', 'weekly' or 'monthly' then, during 'Summer Time', the archive will occur an hour late (i.e. at 01:00 hrs. instead of midnight).

4.3.6 ARCHIVE CONFIGURATION (Cont.)

ARCHIVE TO REMOTE

Note: Archive to remote is available only if the Ethernet option is fitted

For Remote settings only:

None	Archive to host is initiated by the operator (section 4.1.2)
Hourly	Archive to host occurs on the hour every hour
Daily	Archive to host occurs at 00:00* hrs each day
Weekly	Archive to host occurs at 00:00* hrs every Monday
Monthly	Archive to host occurs at 00:00* hrs on the 1st of each month
Automatic	The recorder selects the slowest out of 'Hourly', Daily, Weekly or Monthly, which is guaranteed not to lose data (depends on the size of the Trend History Buffer).

*Note: Archive times are not adjusted for Daylight Saving hour changes. Thus if the archive is set to 'daily', 'weekly' or 'monthly' then, during 'Summer Time', the archive will occur an hour late (i.e. at 01:00 hrs. instead of midnight).

REMOTE PATH

For Remote settings only:

The route to a folder or directory on the remote host, set up as a part of that host's FTP configuration

PRIMARY REMOTE HOST

For Remote settings only:

If a Domain Name Server (DNS) is specified in the Network key 'Name' page (fig 3.2.3b), then the Primary Remote Host is the server name. If DNS is not selected, then the Primary Remote Host is the IP address of the remote host, set up in the host's Control Panel\Network.

PRIMARY LOGIN NAME/PASSWORD

For Remote settings only:

Login name and password of the remote host account assigned either by the Network administrator, or in the Guest account of the remote host's FTP services or User Manager configuration. The password, which must be of between eight and 20 characters, must be entered twice to ensure integrity.

SECONDARY REMOTE HOST/LOGIN/PASSWORD

For Remote settings only:

As for primary versions, but for a secondary host. The secondary route is used only if the primary route fails.

4.4 SECURITY

Touching this key allows the operator to select 'Login' (described in [section 3.3.1](#)) 'Access' or 'Add/Remove User' for configuration. Selecting 'Access' displays the current user level. Touching this area allows the user to select 'Logged out', 'Operator' or 'Engineer'. The user may also go directly to logged out mode by operating the 'Logout' key.




Figure 4.4 Security configuration menus

4.4.1 Access levels

There are essentially three levels of security associated with the recorder viz: Engineer, Operator and Logged out. (The fourth level - Service - is available only to service engineers). When logged-in at engineer level, the user can set access permissions for Operator and logged-out levels, and can enter or edit passwords for Operator and Engineer levels. The password for Engineer level is set to 10 at the factory. The password for Operator level is set to zero at the factory.

Note: To allow free access to the recorder configuration, the password can be set to 0 (zero). This allows subsequent access without a password having to be entered.

Users with Full Security permission can Add (and Delete) users (sections 4.4.2, 4.4.3) and assign them individual passwords and access permissions. User names (IDs) appear in the 'Login' and 'Access When' picklists.

SETTING PERMISSIONS

Once logged in at Engineer level, operate the 'Security' key and select 'Access'. A page similar to that shown in figure 4.4.1 appears, allowing the permissions to be set for the various access level and for individual users. The list of parameters is the same for all access levels except for 'Logged out', for which the password parameters and 'login disabled' items do not appear.

4.4.1 ACCESS LEVELS (Cont.)




Figure 4.4.1 Access permissions menu

ACCESS WHEN:

Allows an access level or an individual user ID to be selected from a pick list.

NEW PASSWORD/RETYPE PASSWORD

For all levels except Logged Out, these fields allow a new password to be entered for the selected access level or User. The password must be entered in the 'Re-type Password' field. If the two differ, a warning message (Passwords did not match) appears when the APPLY key is operated, and password entry must be repeated.

CONNECT FROM REMOTE

Enabling this field, calls the Remote user name and Remote user password entry boxes.

REMOTE USER NAME/PASSWORD

These two entry boxes allow user name and password to be entered for use by the remote host operator. The remote user will be able to access the recorder configuration according to the other access permissions enabled in this page. The password must be entered twice to ensure integrity.

To allow unrestricted view-only to the host, 'Logged out' permission level should be selected and then a user name of 'anonymous' entered, and the password field left blank.

Note: Remote login will be refused if the user account is disabled for any reason.

LOGIN DISABLED

For all levels except Logged Out, this allows any one or more of the access levels do be removed from the 'Access when' picklist.

Note: This feature should be used with discretion, or the situation might arise in which the recorder cannot be logged onto, either at a particular access level or at all. It is recommended that at least one user with Engineer-level access is retained with login enabled, or it may become necessary to return the recorder to the manufacturer, or to arrange for a service visit.

4.4.1 ACCESS LEVELS (Cont.)

EDIT OWN PASSWORD

Allows each user, with this permission enabled, to edit his/her password.

CHANGE ALARM SETPOINTS

Allows each user with this permission enabled, to edit alarm parameters under Configuration/Channel

SET CLOCK

Allows each user, with this permission enabled, to set the recorder time and date functions under System/Clock

ARCHIVING CONTROL

Allows each user, with this permission enabled, full access to disk archive control.

SAVE/RESTORE

Allows each user, with this permission enabled, full access to saving and restoring functions as described in [section 4.2](#), above. Without this permission, the SAVE/RESTORE key does not appear.

PASTE/DELETE FILES

Allows each user, with this permission enabled, to Paste and delete files as described in section 5 of this manual.

FULL CONFIGURATION

Allows each, user with this permission enabled, full access the recorder configuration.

FULL SECURITY

Allows each user, with this permission enabled, full access to all recorder security functions.

4.4.2 Add user

Figure 4.4.2 shows that the selecting of 'Add User' from the SECURITY picklist allows new user IDs to be entered, together with passwords, and a chosen set of access permissions, which can subsequently be edited under Security/Access. The ADD key and the APPLY key must both be used to write the change to the recorder data base. The user must have Full Security access in order to add a new user.

NEW USER/NEW PASSWORD/RETYPE PASSWORD

These fields allow a user name (of up to 20 characters) and a password to be entered and confirmed.

BASED ON

This picklist allows another user or access level to be used as a permissions template, to simplify the configuration if several operators are to have identical permissions.




Figure 4.4.2 Add User display page

4.4.3 Remove user

Selecting 'Remove User' from the SECURITY picklist allows user IDs to be removed from the user list. The 'Remove' key and the 'Apply' key must both be used to write the change to the recorder data base. Figure 4.4.3 depicts the display page.




Figure 4.4.3 Remove User display page

4.5 NETWORK CONFIGURATION

Note: The Network key appears only if the Ethernet option is fitted

Operating the Network key calls a selection box to the display, allowing 'Address' or 'Name' to be selected for configuration.

4.5.1 Address

Figure 4.5.1 shows the address menu fields.




Figure 4.5.1 Network addressing

INSTRUMENT NUMBER/MAC ADDRESS

Unique numbers set up during manufacture to identify the recorder to a remote host, or to the recorder manufacturer/distributor, in case of query.

IP ADDRESS LOOKUP

This field allows an address to be entered for the recorder. This can be done either by manually entering an address (IP address field - below), or the network service BootP can be used to assign an IP address to the recorder.

BOOTP TIMEOUT

This is the maximum time the recorder will wait, at power-up, for a response from the BootP server. If no response is received within this time, the IP address, Subnet mask and Default gateway are all set to, or remain at 0.0.0.0

IP ADDRESS

Allows manual entry of the recorder's internet protocol (IP) address only if 'Specify an IP address' is selected in the 'IP address lookup' picklist above.

SUBNET MASK

This field is editable only if 'Specify an IP address' is selected in the 'IP address lookup' picklist above. The subnet mask is the network address plus the bits in the host address reserved for sub-network identification. By convention, all the network address bits are set to 1. The subnet mask is used to identify the subnet to which an IP address belongs by performing a bitwise AND on the mask and the IP address.

DEFAULT GATEWAY

To deliver traffic from one subnet to another, devices called 'routers' or 'gateways' are placed between segments. The default gateway address informs each network device where to send data if the target station does not reside on the same subnet as the source.

4.5 NETWORK KEY (Cont.)

4.5.2 Name

Figure 4.5.2 shows the 'Name' fields

The screenshot shows a configuration window with the following elements:

- Navigation tabs: Archive, Save/Restore, Config, Security, Network, System.
- A box labeled 'Address Name' with an arrow pointing to the 'Local Host' field.
- Local Host:
- Domain:
- Domain Name Service:
- Primary DNS Server:
- Secondary DNS Server:
- Buttons: Apply, Discard.

Figure 4.5.2 network name fields

LOCAL HOST

English language name for the recorder - Assigned to the IP Address

DOMAIN

The name of the Group or area of networked units which contains the recorder

DOMAIN NAME SERVICE (DNS)

Enables the mapping of host names to IP addresses and *vice-versa*.

PRIMARY/SECONDARY DNS SERVER

IP addresses supplied by IT department or the Domain manager or Supervisor.

Note: Any one or more of the above items may be overwritten if 'IP address lookup' is set to 'Obtain from Bootp Server' as described under 'Address' above.

4.6 STSTEM




Figure 4.6 System configuration menu layout

4.6 SYSTEM (Cont.)

Touching the System key calls the pick list:

Setup
Clock
Locale
Keycode
About

Figure 4.6 above, shows an overview of the System Menus.

4.6.1 Setup

This allows the various display modes described in [section 3.4](#), above to be enabled or disabled, using 'check' boxes. When enabled, a display mode is added to the Cycle key's menu. The 'Home' window allows any one of the enabled display modes to be selected for display when the Home button is pressed in the [Root](#) menu, or when other display pages time-out.

HOME TIMEOUT

The recorder returns to the specified home page after the timeout value of minutes has elapsed since the last touch on the display. Time-out action is inhibited if a configuration is incomplete (there are changes which have not been 'Applied'), or if a system-generated message (e.g. 'Clock Failure') is on display. User displays (e.g. Root menu) are time-out after approximately 50 seconds.

A value of zero disables the time-out function. Valid entries are between 1 and 9999 minutes.

4.6.2 Clock

Selecting 'clock' causes the recorder's date and time to be displayed. To edit the date, touch the current date area, to call the keyboard and enter the new numbers. The date is edited in a similar way. The settings apply as soon as the 'Apply settings' button is touched.

4.6.3 Locale

This allows the setting of the following items:

Language	Choose the required language from the picklist
Country	Displays a pick list of countries associated with the selected language
Time zone*	Select GMT, UTC, ECT, EET, ART, EAT, MET, NET, PLT, IST, BST, VST, CTT, JST, ACT, AET, SST, NST, MIT, HST, AST, PST, PNT, MST, CST, EST, IET, PRT, CNT, AGT, BET, CAT from picklist.
Use Summertime (DST)*	Select box if daylight saving is to be used, If 'Use Summertime (DST)' is selected, the times and dates for the start and end of summertime can be entered using picklists - see figure 4.6

Notes:

1. Date format DD/MM/YY or MM/DD/YY is defined by the language and country selected. Time format (e.g. 12/24 hr clock) is defined by the country selected.
 2. When using Bridge 5000, the host PC's locale information and the recorder locale information should match, or the displayed time will not be correct.
-

*Note: For more information, see <http://www.timeanddate.com>

4.6.4 Keycode

This is a means of allowing new options to be enabled, by the entering of a code, using standard text entry techniques, or by reading a file from a floppy disk. If a File is specified, the first line of the file must be the Key Code. To select the file for reading, the Key Code File field is touched, to display the file list - if necessary, refer to section 5, below, for more details

The Instrument Number, which must be quoted if ordering upgrades, is unique to the instrument and is not user editable.

4.6.5 About

Selecting 'About' gives details of the version numbers of different aspects of the recorder, and details of the amount of memory fitted.

5 FILE

[Figure 5](#), below, gives an overview of the File Menus. The area is entered by touching the 'File' key of the [root](#) menu, and can be used to display the contents of directories stored both in the user area of flash memory and on any disk currently inserted.

The first display page shows the 'volume' or 'device' names associated with the various areas of memory available to the user. If one of these volume names is selected (touched), and the 'open-folder' key operated, the contents of the selected volume is displayed. This would typically consist of a list of folders. Similarly, if a folder name is selected and the 'open folder' key is touched, the contents of the folder is displayed and so on.

To return to higher levels, the 'close-folder' key is used.

The path name of the current window is shown at the top of the window.

5.1 FILER OPTION MENU KEYS

These keys appear in a pop-up menu when the root menu Options key is pressed. The pop-up menu appears only when an actual file has been selected (i.e. it does not appear if a directory (folder) or volume is selected.) Cut and paste functions are available only to users with the relevant access permissions ([section 4.4](#)).

Cut	Removes a file from the list, ready for 'pasting' to another destination.
Copy	Copies a file from the list, ready for 'pasting' to another destination.
Delete	Removes a file from the memory.
New	Allows a new directory (folder) to be created
Paste	Places a 'cut' or 'copy' file into the new destination.
Refresh	Refreshes the display.

A key's legend is hidden (displayed in white) if at any time its function is not applicable.

5.2 THE HIDE KEY

The Hide key at the top right corner of the display screen is used to hide (show) Type, Date and Bytes information, allowing the full filename text string to appear.

5 FILE (Cont.)




Figure 5 File system overview

6 BRIDGE 5000 REMOTE VIEWER

Note: Bridge 5000 is available only if the Ethernet option is fitted

6.1 INTRODUCTION

This feature allows the user to view recorder standard screens, dynamically, on-line, from any PC which meets or exceeds the minimum requirements listed below. The software is supplied on a CD ROM, which also includes PC review, PC Configuration and Acrobat reader software and various manuals relevant to the recorder.

The Remote viewer software is suitable for any physical hardware configurations, some common examples being:

1. A single PC connected directly to a recorder
2. Multiple PCs connected via a network to one or more recorders. (Each recorder can be accessed by a maximum of four PCs, but one PC can look at a number of recorders depending on available memory. For example, a minimum specification computer (section 6.1.1) running Windows NT can 'look at' up to three recorders.)
3. A single PC connected via a telephone line to a remote recorder.

This manual does not attempt to describe network setup in detail, as each network is different. In most cases, the help of the network administrator or supervisor will be required, for example, in the allocation of valid addresses and passwords.

6.1.1 Minimum PC requirements

1. P90 running Windows 95/98/NT
2. 32MB RAM
3. 50MB free hard disk space
4. Graphics drive capable of displaying > 256 colours (recommended)

6.2 CONNECTION DETAILS

The connection to the recorder is terminated at the RJ45 connector located as shown in figures [2.2.1a](#), [2.2.1b](#)). The other end of the cable may be terminated, for example, at a hub, a dial-up router or a PC, and it is up to the user to obtain a suitable cable (normally available from a computer supplier or electronic component distributor.)

Note: For direct connection between a PC and the recorder, a crossover cable is required. For all other connections, a 'straight-through' connection is required.

6.2.1 Direct PC connection

The RJ45 connector at the rear of the recorder is connected via a crossover cable to the PC network card connector.

6.2 CONNECTION DETAILS (Cont.)

6.2.2 PC To remote recorder

As shown in figure 6.2.2, one or more recorders' Ethernet connector can be connected to a Dial Up Router, plugged into a telephone socket. The PC must similarly be connected to a telephone socket via a modem (shown external in the figure, but often built-in with modern computers.)

The dial-up router (available from computer suppliers etc.) has an associated telephone number, and can also have a security password system. Both the telephone number and any password(s) must be known to the PC user before any attempt at communication is made.

The PC can be set up to dial the number automatically, or the number may be dialed manually. Reference should be made to the computer documentation or help pages if necessary.

Once communication has been established, the software can be run.




Figure 6.2.2 Remote connection example

6.2.3 Networked systems

For PCs and recorders connected into an internal network, it is necessary only to obtain an IP address (or name) and the required passwords in order to establish connections between the PC(s) and the recorder(s).

For PCs remote from a networked system which is permanently connected to the internet, it is necessary to obtain an IP address (or name) and the required passwords in order to establish connections between the PC and the recorder(s). In many cases it is also necessary that the internal network and 'firewall' (if such exists) be configured to allow access.

For PCs remote from a networked system which is not connected to the internet, a system similar to that shown in figure 6.2.2 is needed.

6.3 SOFTWARE INSTALLATION

Insert the CD ROM into the PC slot, and in 'My Computer' open the CD drive. A number of items appear, including a 'Read-me' file, which gives instruction on how to install the software.

Press setup.exe.

When the Bridge 5000 display appears, the installation procedure can be completed. Refer to the 'Read-me' file as required.

6.4 RECORDER CONFIGURATION

The recorder configuration is in three areas: Network, Options and Access,

6.4.1 Network

The Network key fields are fully described in section 4.5 of this manual

6.4.2 Options

In order to make the option accessible, it must first be correctly entered in the Options Menu.

If the number of Remote Viewers displayed does not match the 'currently' number (if displayed), operation of the 'Autoconfigure' key will add the option to the database.

If all options are correctly entered, the 'Currently' fields and the Autoconfigure key do not appear.




Figure 6.4.2 Options menu

6.4.3 Access

Each of the access levels and user IDs can have 'Connect from Remote' access enabled. When this box is checked, password entry fields appear as shown in figure 6.4.3. Initially, the Remote User Name is the same as the login name or access level. Enter the required User name and password (eight to 20 characters), then re-type the password to ensure it was entered correctly. This name and password are required when establishing connection with the host computer.

Access when Fred

New Password *

Retype Password *

Connect from remote

Remote user name Fred

Remote password *

Retype remote password *

Login Disabled

Edit own Password

Change Alarm Setpoints

Set Clock

Archiving Control

Save/Restore

Paste/Delete Files

Full Configuration

Full Security

Batch Control

Batch control is not supported by this software version

Apply Discard

Figure 6.4.3 Remote user access fields

6.5 RUNNING THE PROGRAM

Click on the **START** key, and then on the program called 'Eurotherm' or 'Recorder'. Select 'Bridge 5000'.

Once the program starts, a Host name and User name will be requested as depicted in figure 6.5a.

Enter the Local host name found in the recorder Network/Name area, followed by a dot (full stop, period) followed by the domain name (also in the Network/Name area).


Notes

- 1 If frequent use is to be made of this option, it is recommended that a 'short-cut' be created, and placed on the computer desktop. To create a new bridge 5000 link: right click on the desktop, left click 'New' in the pop up menu which appears, then left click on the Bridge 5000 icon. When naming Bridge 5000 files, the extension .uhv must be used.
 - 2 If there is no Bootp or other, similar, server associated with the system, the IP address (found in the recorder Network/Address area) should be used instead
 3. The PC locale setting (e.g. Daylight Saving Time) must match that set in the recorder ([System/Locale](#)) or the displayed time will be incorrect.
-

Enter the user name as entered in the recorder's Security/Access/Remote user name field (section 6.4.3).

If password entry is not required, disable the tick box (goes blank), then press 'Start' to start running the program

If a password entry is required, ensure that the password required tick box is enabled (tick visible). Press 'Start', then enter the password (as entered in the Security/Access/Remote User Name/Remote password field), followed by carriage return to start running the program.



Bridge 5000 Configuration

Host name

User name

Password required

START

Figure 6.5a Host /User name selection



Figure 6.5b Bridge 5000 icon (approximation)

6.6 OPERATION

6.6.1 Display Modes

When the program starts, the Vertical Trend page is displayed on the computer screen. Operating the Root Menu key, then 'Cycle' calls the Horizontal Trend display. Further operations of the above keys cycle through the remaining display modes described in [Section 3](#), above, whether or not they are enabled in the recorder [System Setup](#).. The Vertical Trend display can be returned-to at any time, by operating the Root Menu key followed by the Home key.

Notes

1. Trend review is not available.
 2. Any changes to the recorder's group configuration are reflected immediately at the Remote Viewer screen.
-

By click-dragging on the bottom right hand corner of the display, the page size can be sized as required. It is thus possible for the computer to log on to, say four, different recorders and to display their values simultaneously in different parts of the display screen.

6.6.2 Alarm acknowledgement

The alarm acknowledgement/read messages function are as described in [section 3.1.3](#), above

6.6.3 Status line

The status line at the top of the screen reflects the status of the instrument to which the recorder is connected - e.g. system messages, global alarm, FTP, clock etc.

6.6.4 Error messages

A number of error conditions may occur to prevent the remote viewer from 'viewing' the recorder. Any such conditions may be viewed by touching the alarm icon at the top of the screen, as described in [section 3.1.3](#) of the Installation and Operation manual. The following messages can appear:

NETWORK CONNECTION HAS TIMED OUT

This message appears when no connection can be established between the remote viewer and the instrument. This might be caused by, for example, cable failure, the instrument's not being powered, network hardware failure etc.

UNABLE TO CONNECT TO HOST ...

Similar to the timeout message above, but with the additional cause: incorrect host address.

UNABLE TO RESOLVE HOSTNAME

Caused by an incorrect host address, or network failure.

FAILED TO AUTHENTICATE THE USER NAME AND/OR PASSWORD SUPPLIED

Caused by incorrect user name or password.

MAXIMUM REMOTE VIEWERS ALREADY CONNECTED TO ...

An attempt is being made to connect more remote viewers to the recorder than are configured in the Options menu.

7 REFERENCE

This section contains diagnostic and servicing details, and overview drawings of the recorder menu structure.

7.1 DIAGNOSTICS DISPLAY

At power-up, continuously hold a finger in contact with the screen until (after approximately 30 seconds) the diagnostic display appears as shown in figure 7.1. If no further action takes place within approximately five minutes, the display times-out to the calibration display.




Figure 7.1 Top-level diagnostic display

7.1.1 Display details

MAC ETHERNET ADDRESS

This unique hex address is for factory use only. See [section 4.5.1](#) for the instrument's full MAC address.

COLOUR TEST BARS

This colour 'swatch' allows a judgement to be made as to the correctness of the display colour rendering.

SOFTWARE VERSION NUMBER

This shows the version number of the software fitted to the recorder.

SELF-TEST STATUS BARS

These four areas show the status of the main circuit board (MAIN), the disk fitted (MEDIA), the battery and the Ethernet/relay option board (not yet implemented). In each case, if the bars are grey, then no faults have been detected; if any one or more of them is flashing red/white, then a fault has been found.

MAIN

This tests the Dynamic RAM (DRAM), the Static RAM (SRAM) and the flash memory. The results can be displayed by operating the 'Detail' key. See [figure 7.1.1](#).

(Continued)

SELF-TEST STATUS BARS (Cont.)**MEDIA**

This sends a message to the disk, and then tries to read it back. Failure to succeed might be any one or more of the following:

1. No disk was fitted when the test was initiated.
2. The disk is unformatted or incorrectly formatted.
3. The disk is too full (less than 1kB remaining) for the message to be written to it.

BATTERY

This area flashes when the battery needs to be replaced (section 7.3). The test is performed once every 15 minutes.

ETHER

Not applicable to this release.

CIRCUIT BOARDS FITTED

The major part of the display screen is taken up with a representation of the rear of the recorder, showing what input and output cards are fitted in each circuit board slot. 1_Relay represents the Ethernet/Relay output board; AI_6 represents the six analogue inputs on the main board.

TOUCH CAL

This key initiates the display calibration (offset correction) procedure, described in section 7.2 below.

DETAIL

Touching this key causes the main board test results to be displayed, as shown in figure 7.1.1 below.

To quit diagnostics, switch the recorder off, then, after a few seconds, switch it back on again




Figure 7.1.1 Main board self-test results display

7.2 SCREEN CALIBRATION (OFFSET CORRECTION)

This procedure ensures that the display screen image is positioned correctly, compared with the touch screen (so that 'what you touch is what you get'). The procedure, is necessary only rarely, if at all, and is included here only for the sake of completeness.

1. At power-up, continuously hold a finger in contact with the screen until (after approximately 30 seconds) the diagnostic display appears as shown in figures 7.1a/b. Operate the Touch cal key to call the first calibration screen, as depicted in figure 7.2*
2. Using a soft, small-diameter item (e.g. a pencil point) which will not damage the touch screen, touch the intersection of the upper set of crosshairs, as requested by the display and keep touching it until the next target appears..
3. Continue the process, according to the directions appearing on the screen. Once all the 'targets' have been accepted, the recorder returns to the diagnostic display.

Note: The diagnostic display times-out (to the screen calibration page) after about 5 minutes. The screen calibration pages time-out to the diagnostic page after a time which depends on how much of the calibration procedure has been completed




Figure 7.2 Initial calibration display

7.3 PREVENTIVE MAINTENANCE

7.3.1 Touch Screen Cleaning

CAUTION

The touch-sensitive screen used in this product is designed for use by hand only. The use of sharp or pointed implements such as pens, keys and fingernails to operate the instrument must be avoided, or irreparable damage will be done to the surface material. When cleaning the touch-screen, a moist cloth should be used, if necessary with a minimal amount of mild soap solution.

ALCOHOLS SUCH AS ISOPROPYL ALCOHOL MUST NEVER BE USED ON THE SCREEN.

7.3.2 Maintenance schedule

Battery replacement - Every three years

7.3.3 Battery replacement procedure

Notes:

1. The battery is of poly-carbonmonofluoride/lithium construction and should be disposed of according to local regulations covering this type of battery.
2. It is recommended that the recorder be isolated from mains (line) power before the battery is replaced. All battery backed RAM data is lost during battery change.

1. Remove the mains connector. For convenience, disconnect the relay and Ethernet connectors (if fitted).
2. Remove the rear terminal cover (A) by pressing down on the catch and lifting off. Remove the input connector (B), by pressing-in on the end clips and pulling on the connector (figure 7.3.2a).
3. Remove the three screws 'C' in figure 7.3.2b.
4. Carefully lift the front of the recorder case cover, and disconnect the two looms connecting it to the internal circuit board (figure 7.3.2c)
5. Push the battery out of its holder as shown in figure 7.3.2d.
6. Install the new battery by pushing it into position (+ uppermost).
7. Re-connect the two looms previously disconnected, then re-assemble the recorder.




Figure 7.3.2a Remove terminal cover and connector




Figure 7.3.2b Release cover plate




Figure 7.3.2c Disconnect looms; Remove cover plate




Figure 7.3.2d Replace battery

7.4 MENU STRUCTURE




Figure 7.4a Menu structure sheet 1




Figure 7.4b Menu structure sheet 2

7.4 MENU STRUCTURE (Cont.)




Figure 7.4c Menu structure sheet 3




Figure 7.4d Menu structure sheet 4

ANNEX A: SPECIFICATION

INSTALLATION CATEGORY AND POLLUTION DEGREE

This product has been designed to conform to BS EN61010 installation category II and pollution degree 2. These are defined as follows:

Installation category II

The rated impulse voltage for equipment on nominal 230V ac mains is 2500V.

Pollution degree 2

Normally, only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation shall be expected.

TECHNICAL SPECIFICATION (Recorder)**Inputs/Outputs**

6-channel universal input
 1 Change-over relay output board (optional)
 3.5 inch floppy disk

Optional features

File transfer protocol (FTP)
 Bridge 5000 Remote viewer

Environmental Performance

Temperature limits	Operation:	5 to 40°C
	Storage:	-20 to + 50°C
Humidity limits	Operation:	20% to 80% RH (non - condensing)
	Storage:	20% to 80% RH (non - condensing)
Altitude (maximum)		<2000 metres
Protection	Bezel and display:	IP65
	Sleeve:	IP20
Shock		BS EN61010
Vibration (10 Hz to 150Hz)		2g peak

Physical

Panel mounting	DIN43700
Bezel size	144mm x 144mm
Panel cutout	138mm x 138mm (-0.0 + 1.0) mm
Depth behind bezel	248 mm (213mm without terminal cover)
Weight	3 kg. max.
Mounting angle	±15 ° from vertical

Electromagnetic compatibility (EMC)

Emissions and immunity BS EN61326

Electrical safety

BS EN61010. [Installation category II](#), [Pollution degree 2](#)

Power requirements

Line voltage	47 to 63 Hz:	85 to 265V
Power (max.)		60 VA (Inrush current 36A)
Fuse type		None
Interrupt protection		Holdup >200msec. at 240V ac, with full load.

Back-up battery

Type	Poly-carbonmonofluoride/lithium (BR2330). Part Number PA261095
Support time	A fully-charged, new battery supports the Real-Time Clock for a minimum of 1 year with the recorder unpowered
Replacement period	3-years

Operator interface

Colour STN LCD with cold cathode backlighting, fitted with resistive, analogue, toughened touch panel.
 Screen specification 1/4 VGA Resolution = 320 x 240 pixels

Update/archive rates

Input/relay output sample rate:	8 Hz.
Display update:	1 Hz,
Archive sample value:	Latest value at archive time
Trended/displayed value:	Latest value at display update time

TECHNICAL SPECIFICATION (Universal inputs)

General

Termination	Inputs:	22 - way Edge connector/terminal block
Max. number of inputs		six
Input ranges		-38 mV to +38mV; -150 mV to +150mV; -1 Volt to +1Volt; -10 Volts to + 10Volts
Input types		Dc volts, dc millivolts, dc milliamps, (with external shunt), thermocouple, 2/3 wire resistance temperature detector (RTD), Ohms, Contact closure (not channel 1) (Minimum contact closure = 60msec.)
Input type mix		Freely configurable
Sample rate		See 'Update information' above
Noise rejection (48 to 62Hz)		
	Common mode:	>140dB (Channel to channel and channel to ground)
	Series mode:	>60dB
Maximum common mode voltage		250Volts continuous
Maximum series mode voltage		45mV at lowest range; 12Volts peak at highest range
Isolation (dc to 65Hz; BS EN61010)		Installation category II; Pollution degree 2 300V RMS or dc channel to channel (double insulation), channel to common electronics (double insulation) and channel to ground (basic insulation)
Dielectric strength	Channel to ground:	1350Vac for 1 minute.
	Channel to channel:	2300Vac for 1 minute
Insulation resistance		>10MΩ at 500V dc
Input impedance	10V range:	68.8kΩ
	Other ranges:	>10MΩ
Overvoltage protection		50V peak (150V with attenuator)
Open circuit detection		± 57nA max
	Recognition time:	500mSec
	Minimum break resistance:	10MΩ

DC input ranges

Shunt	Externally mounted resistor modules
Additional error due to shunt	0.1% of input
Performance	See table

Low Range	High Range	Resolution	Maximum error (Instrument at 20°C)	Worst case temperature performance
-38 mV	38 mV	1.4 μV	0.085% input + 0.051% range	80ppm of input per deg C
-150 mV	150 mV	5.5 μV	0.084% input + 0.038% range	80ppm of input per deg C
-1 V	1 V	37 μV	0.084% input + 0.029% range	80ppm of input per deg C
-10 V	10 V	370 μV	0.275% input + 0.030% range	272ppm of input per deg C

TECHNICAL SPECIFICATION (Universal inputs) (Cont.)**Resistance inputs**

Temperature scale	ITS90
Types, ranges and accuracies	See tables (values exclude influence of lead resistance)
Influence of lead resistance	Error: Negligible
Mismatch:	1Ω/Ω

Low Range	High Range	Resolution	Maximum error (Instrument at 20°C)	Worst case temperature performance
0Ω	150Ω	5mΩ	0.035% input + 0.110% range	35ppm of input per deg C
0Ω	600Ω	22mΩ	0.035% input + 0.065% range	35ppm of input per deg C
0Ω	6kΩ	148mΩ	0.035% input + 0.035% range	35ppm of input per deg C

RTD type	Overall range (°C)	Standard	Max.linearisation error
Cu10	-20 to + 400	General Electric Co.	0.02°C
JPT100	-220 to + 630	JIS C1604:1989	0.01°C
Ni100	-60 to + 250	DIN43760:1987	0.01°C
Ni120	-50 to + 170	DIN43760:1987	0.01°C
Pt100	-200 to + 850	IEC751	0.01°C
Pt100A	-200 to + 600	Eurotherm Recorders SA	0.09°C
Pt1000	-200 to + 850	IEC751	0.01°C

Thermocouple data

Temperature scale	ITS90
Bias current	0.05nA
Cold junction types	Off, internal, external, remote (Remote CJ is not currently implemented - check availability)
CJ error	1°C max with instrument at 25°C
CJ rejection ratio	50:1 minimum
Remote CJ	via any user-defined input channel (Remote CJ is not currently implemented - check availability)
Upscale/downscale drive	Types: 'High', 'low' or 'none' selectable for each thermocouple channel.
Additional error:	Typically 0.01°C - depends on wiring. (Detect current = 57nA.)
Types, ranges and accuracies	See table

T/C type	Overall range (°C)	Standard	Max.linearisation error
B	0 to + 1820	IEC584.1	0 to 400°C = 1.7°C 400 to 1820°C = 0.03°C
C	0 to + 2300	Hoskins	0.12°C
D	0 to + 2495	Hoskins	0.08°C
E	-270 to + 1000	IEC584.1	0.03°C
G2	0 to + 2315	Hoskins	0.07°C
J	-210 to + 1200	IEC584.1	0.02°C
K	-270 to + 1372	IEC584.1	0.04°C
L	-200 to + 900	DIN43700:1985 (To IPTS68)	0.02°C
N	-270 to + 1300	IEC584.1	0.04°C
R	-50 to + 1768	IEC584.1	0.04°C
S	-50 to + 1768	IEC584.1	0.04°C
T	-270 to + 400	IEC584.1	0.02°C
U	-200 to + 600	DIN43710:1985	0.08°C
NiMo/NiCo	-50 to + 1410	ASTM E1751-95	0.06°C
Platinel	0 to + 1370	Engelhard	0.02°C

TECHNICAL SPECIFICATION (Ethernet/Relay output board option)**Network Communications**

Type	IEEE802.3 10BaseT
Cable	Type: CAT5
	Maximum length: 100 metres
	Termination: RJ45 telephone connector
Transport protocol	TCP I/P, FTP

Relay

GENERAL

Number of relays per board	One
Maximum number of relay boards	One
Type	Single pole changeover (form C)
Termination	Three-way connector
Estimated mechanical life of relay	30,000,000 operations
Maximum switching power	500VA or 60W
Maximum contact voltage	250V providing this does not cause the maximum switching power (above) to be exceeded
Maximum contact current	2 Amps providing this does not cause the maximum switching power (above) to be exceeded
Update rate	See ' Update/archive rates ' in 'Universal inputs specification' above


SAFETY ISOLATION

Isolation (dc to 65 Hz; BS EN61010)	Installation category II ; Pollution degree 2
Relay to common electronics:	300V RMS or dc (double insulation)
Relay to ground:	300V RMS or dc (basic insulation)

DERATING

The figures given in 'General', above, are for resistive loads. For reactive or inductive loads, de-rate in accordance with the figure below, in which

- F1 = Actually measured results on representative samples
- F2 = Typical values (according to experience)
- Contact life = Resistive contact life x reduction factor.



INDEX

A

About	51
Absolute high/low	36
AC supply voltage range	9
Access	
Levels	43
To configuration	15
Access when:	44
ACK Message	37
Acknowledging alarms	13, 36, 37
Add user	46
Address	
IP	47
MAC	47, 59
Alarm	
Acknowledgement	11, 13, 36, 37, 58
Message enable/disable	37
Configuration	35
Icons (Channel)	10
Message enable/disable	37
Messages	36
Type	35, 36
Archive	
Configuration	40
Control permission	45
Key	26
Manual initiation to disk	26
Manual initiation to host	27
Period selection (disk)	41
To Remote	42

B

Bargraph displays	22
Battery	
Diagnostics	60
Icon	13
Replacement	62
BootP timeout	47
Break response	34
Brightness control	39
BSpC	16

C

Cable	
Signal, Max/min sizes	8
Supply voltage (min. size)	9
Caps	16
Change	
Alarm setpoint permission	45
Battery	
Indicator	13
Procedure	62
Channel	
Colour	35
Configuration	32 to 42
Damping	34
Descriptor	35
Character set	16
CJC	34
Cleaning	61

C (Cont.)

Clock setting	50
Cold junction compensation	34
Configuration	
Access	15
Alarm	35
Archive	40
Break response	34
Channel	32 to 42
Cold junction compensation	34
Country	50
Date format	50
Decimal point	35
Display brightness settings	39
Dwell	36
Event	38
Filter	34
Group	37
Input low/high	33
Instrument	30 to 42
Language	50
Linearisation range	34
Linearisation type	33
Network	47
Offset	34
Options	30
Scale	34
Security	43
Shunt value	33
Span	35
Summertime	50
System	39
Time and date	50
Time zone	50
Trace Colour	35
Zone	35
Connect from Remote	44
Connector locations	8
Contents of group	37
Contrast control	11
Copy key	51
Country, Selection of	50
Cursor keys	14
Cut key	51

D

Damping	34
Data compression ratio	41
Date and time setting	50
Date format	50
Daylight saving setup	50
DC supply voltage range	9
Decimal point position	35
Default Gateway	47
Delete key	51
Descriptor	
Channel	35
Event	38
Group	11, 37
Instrument	39

D (Cont.)

Detail	60
Diagnostics display	59
Disable login	44
Disk	
Access	9
Activity indicator	13
Free space	13
Full response	41
Icon	13
Size	41
Display	
Brightness	39
Calibration	61
Contrast	11
Modes	18 to 24
Enable/disable	50
Home selection	50
Horizontal bars	23
Horizontal Trend	20
Numeric	24
Vertical bars	22
Vertical Trend	18
Update rate	68
Values (truncation of)	10
Domain	48
Name Service	48
Dwell	36

E

Engineer, Access level	15, 43
Error indicator	11
Error messages (FTP)	58
Ethernet	
Address	59
Specification	71
Event configuration	38
Exclamation mark symbol	12

F

Faceplates (on/off)	22
File	51
File transfer (FTP) facility	27
Filer Option menu	51
Filter	34
First switch-on	15
Flash size	41
Folder keys	14
FTP Icon	13

G

Group	
Configuration	37
Name	11, 37

H

Hardware version	51
History	37
Amount of	18, 41
Home timeout	50
Horizontal bargraph display	23
Hysteresis	36

I

Input	
Board specification	69
Configuration	33
Low/high	33
Type selection	33
Inserting and Removing Disk/PC cards	9
Installation	
Category	67
Electrical	8 to 9
Mechanical	6 to 7
Instrument	
Name	39
Number	47
IP Address	47
Look-up	47
Manual entry	47

J

Jobs	36, 38
------------	--------

K

Keycode	51
---------------	----

L

Labelling symbols	5
Language selection	50
Latched	36
Left cursor key	14
Linearisation function	33
Local Host	48
Logged out	15
Login	15
Disable	44
Key	14
Logout key	43

M

MAC Address	47, 59
MAIN (Diagnostics)	59
Maintenance	61
Manual archive	
To disk	26
To host computer	27
MEDIA (Diagnostics)	60
Media size	41
Memory size	41, 51
Messages	
Alarm	36
Enable/disable	37
Minimum PC requirements	53

N

Navigation keys	14
Network	
Configuration	47
Name	48
Specification	71
New	
Configuration	29
Key	51
Password	44

O

Offset	34
Correction (touch screen)	61
Ok	16
Open/Close folder keys	14
Operator	
Access level	15, 43
Option	
Configuration	30
Options	
Key	14
Ovr	16

P

Passwords	43
Editing	43
Paste key	51
Paste/delete file permission	45
PC Card access	9
Pollution degree	67
Preventive maintenance	61
Primary	
DNS Server	48
Login Name	42
Remote Host	42

R

Range low/high/units	34
Recorder	
Configuration. <i>See Section 4.3</i>	
Dimensions	7
Electrical installation	8
Panel installation	6, 7
Specification	68
Unpacking	6
Wiring	8
Recording speed/interval	37
Refresh key	51
Relay Board specification	71
Remote	
Path	42
User name/password	44
Remote viewer	
Alarm acknowledgement	58
Configuration	
Access menu	56
Network menu	47
Options menu	55
Connection details	53
Minimum PC requirements	53
Operation	58
Running the program	57
Software installation	54
Remove user	46
Restore	29
Review	37
Maximum history	18, 41
Right cursor key	14
Root key	14
RTD type selection	33

S

Safety notes	5
Sample rates	68
Save/Restore	28
Permission	45
Scaled tick box	34
Screen	
Calibration	61
Saver	39
Secondary	
DNS Server	48
Login	42
Password	42
Remote Host	42
Security	
Configuration	43
Levels	43
Service level access	15
Set clock permission	45
Setting the time and date	50
Shift	16
Show Disk settings	41
Shunt value entry	33
Signal Wiring	8
Software version	51
Span Configuration	35
Specification	
Input board	69
Recorder, general	68
Relay board	71
Status bar	11
Subnet Mask	47
Summertime setup	50
Supply voltage	9
Symbols used on labels	5
System	
Configuration	39, 49
Error indicator	12
Setup	50

T

Tag, Channel	35
Text	
Save and Restore	29
String entry	16
Thermocouple type selection	33
Threshold	36
Time	
Format	50
Permission to set	45
Setting	50
To fill disk/memory	41
Zone selection	50
Timeout	50
Touch Cal	60
Touch screen	
Calibration	61
Precautions	61
Trace	
Colour	35
History, maximum	41
History display	18, 37

T (Cont.)

Trend	
Interval/Speed/Units	37
Review	18
Speed/interval	37
Trigger	36
Truncation of display values	10

U

Unlatched	36
User	
Adding and removing	46
Password	46

V

Value entry	16
Version numbers	51
Vertical bargraph display	22

W

Wiring	
Signal	8
Max/min wire sizes	8
Maximum torque	8
Supply voltage	9

Z

Zone configuration	35
--------------------------	----

This page is deliberately left blank

Inter-Company sales and service locations

Australia

Eurotherm Pty. Limited.
Unit 10,
40 Brookhollow Avenue,
Baulkham Hills,
NSW 2153

Telephone: 61 2 9634 8444
Fax: 61 2 9634 8555
e-mail: eurotherm@eurotherm.com.au
<http://www.eurotherm.com.au>

Austria

Eurotherm GmbH
Geiereckstraße 18/1,
A1110 Wien,

Telephone: 43 1 798 76 01
Fax: 43 1 798 76 05
e-mail: eurotherm@eurotherm.at
<http://www.eurotherm.at>

Belgium

Eurotherm BV,
Kontichsesteenweg 54
2630 Aartselaar
Antwerpen

Telephone: 32 3 320 8550
Fax: 32 3 321 7363

Denmark

Eurotherm Danmark A/S
Finsensvej 86,
DK 2000 Fredriksberg,

Telephone: 45 38 871622
Fax: 45 38 872124

Finland

Eurotherm Finland,
Aurakatu 12A,
FIN-20100 Turku

Telephone: 358 2 25 06 030
Fax: 358 2 25 03 201

France

Eurotherm Automation Division Chessell
Parc d'Affaires,
6, Chemin des Joncs,
BP55

F - 69574 Dardilly, CEDEX
Telephone: 33 0 4 78 66 55 20
Fax: 33 0 4 78 66 55 35

Germany

Eurotherm Deutschland GmbH
Ottostraße 1,
65549 Limburg

Tel: +49 (0) 64 31/2 98 - 0
Fax: +49 (0) 64 31/2 98 - 1 19
e-mail: info@regler.eurotherm.co.uk
<http://www.eurotherm-deutschland.de>

Great Britain

Eurotherm Limited,
Faraday Close,
Worthing,
West Sussex BN13 3PL

Telephone: +44 (0)1903 268500
Fax: +44 (0)1903 265982
e-mail: Sales@recorders.eurotherm.co.uk
or: Support@recorders.eurotherm.co.uk
<http://www.eurotherm.co.uk>

Hong Kong

Eurotherm Limited,
Unit D, 18/F Gee Chang Hong Centre,
65, Wong Chuk Hang Road,
Aberdeen.

Telephone: 852 2873 3826
Fax: 852 2870 0148
e-mail: eurotherm@eurotherm.com.hk

India

Eurotherm DEL India Limited,
152, Developed Plots Estate,
Perungudi,
Chennai 600 096,

Telephone: 91 44 4961129
Fax: 91 44 4961831
e-mail: info@eurothermdel.com
<http://www.eurothermdel.com>

Italy

Eurotherm SpA,
Via XXIV Maggio,
I-22070 Guanzate,
Como.

Telephone: 39 031 975111
Fax: 39 031 977512
e-mail: info@eurotherm.it
<http://www.eurotherm.it>

Japan

Densei Lambda K.K.,
Strategic Products Dept.
5F Nissay Aroma Square,
37-1, Kamata, 5-Chome,
Ohta-ku,
Tokyo 144-8721

Telephone: 81 3 5714 0620
Fax: 81 3 5714 0621
e-mail (Sales): k.iwama@densai-lambda.com
e-mail (Technical): v.rendle@densai-lambda.com
<http://www.densei-lambda.com>

Korea

Eurotherm Korea Limited,
J- Building
402-3
Poongnab-Dong,
Songpa-Ku
Seoul, 138-040

Telephone: 82 2 478 8507
Fax: 82 2 488 8508

Netherlands

Eurotherm BV,
Genielaan 4,
2404CH Alphen aan den Rijn,
The Netherlands

Telephone: 31 172 411 752
Fax: 31 172 417 260
<http://www.eurotherm.nl>

Norway

Eurotherm A/S,
Vollsveien 13D
1366 Lysaker,
Postboks 227
NO-1326 Lysaker
Norway,

Telephone: 47 67 592170
Fax: 47 67 118301
<http://www.eurotherm.no>

Spain

Eurotherm España SA,
Pol. Ind. De Alcobendas,
Calle de la Granja 74,
28108 Alcobendas,
Madrid.

Telephone: 34 91 661 60 01
Fax: 34 91 661 90 93
<http://www.eurotherm.es>

Sweden

Eurotherm AB,
Lundavägen 143,
S-21224 Malmö.

Telephone: 46 40 38 45 00
Fax: 46 40 38 45 45
<http://www.eurotherm.se>

Switzerland

Eurotherm Produkte (Schweiz) AG,
Schwerzistraße, 20,
CH-8807 Freienbach.

Telephone: 41 55 415 44 00
Fax: 41 55 415 44 15
e-mail: epsag@eurotherm.ch
<http://www.eurotherm.ch>

United States of America

Eurotherm Recorders Inc.
741-F Miller Drive
Leesburg
VA 20175-8993

Telephone: 1 703 669 1342
Fax: 1 703 669 1307
e-mail (Sales): sales@chessell.com
e-mail (Technical): support@chessell.com
<http://www.chessell.com>

Informações sobre programação
www.soliton.com.br - e-mail: soliton@soliton.com.br

SOLITON CONTROLES INDUSTRIAIS LTDA

Rua Alfredo Pujol, 1010 - Santana - São Paulo - SP. Tel:11 - 6950-1834 / Fax: 11 - 6979-8980 - e-mail: vendas@soliton.com.br

